

# FreshFlow Beverages Pvt. Ltd.

FreshFlow Bottling Plant - Pune Production Facility  
FSSAI: 10012022000345 | ISO 22000:2018 / ISO 14001:2015

## STANDARD OPERATING PROCEDURE

### Startup Procedure for Syrup Preparation Line 61

Department: Syrup Preparation

|                                                  |
|--------------------------------------------------|
| Document Number: SOP-061                         |
| Revision: Rev 3.1                                |
| Classification: CONFIDENTIAL - INTERNAL USE ONLY |
| Prepared by: Engineering / QA Department         |
| Approved by: Plant Manager                       |

Document Control Information

| Parameter        | Value                                               |
|------------------|-----------------------------------------------------|
| SOP Number       | SOP-061                                             |
| Title            | Startup Procedure for Syrup Preparation Line 61     |
| Department       | Syrup Preparation                                   |
| Plant            | FreshFlow Bottling Plant - Pune Production Facility |
| Prepared By      | Arjun Nair                                          |
| Reviewed By      | Farah Shaikh                                        |
| Approved By      | Rajesh Kulkarni - Plant Manager                     |
| Issue Date       | 2023-11-10                                          |
| Next Review Date | 2025-01-11                                          |
| Revision         | Rev 2.3                                             |

1. Purpose

Prepare sugar syrup batches to the correct Brix and quality specification for use in product blending, ensuring food safety and batch traceability.

2. Scope

Syrup Preparation operators and Shift Supervisors.

3. Prerequisites and Requirements

3.1 Training Requirements

- Syrup preparation training (TRN-SYR-001)
- Food hygiene certification (FSSAI Basic)
- Weighing equipment calibration verification complete

3.2 Tools and Materials Required

- Calibrated instruments as listed in the plant calibration schedule.
- Appropriate PPE as specified in Section 4.
- Completed permit-to-work (if required for maintenance activities).
- Access to relevant equipment manual and P&ID drawings.
- CMMS access to create and close work orders.

## 4. Health, Safety and Environmental Requirements

### ! WARNING

This SOP must not be carried out without appropriate PPE and, where required, a valid Permit to Work (SOP-SAF-006). If in doubt about safety, STOP and consult the Safety Officer (EMP009 / EMP017).

### 4.1 Identified Hazards

- Hot syrup (up to 80°C) - scald risk during heating
- Slip risk from sugar spills on floor
- Chemical handling - antiscaling agents require PPE

### 4.2 Emergency Response

In case of any emergency during this procedure: Press the nearest Emergency Stop, alert personnel in the vicinity, call the Safety Officer and Shift Supervisor. Refer to the Emergency Response Plan (SOP-SAF-004) and site evacuation procedure.

## 5. Detailed Procedure

### 5.1 Pre-Task Verification

1. Confirm the relevant equipment is available and no conflicting activities are planned.
2. Check shift handover log for any outstanding issues with this equipment.
3. Verify all required materials, tools, and chemicals are available and correctly labelled.
4. Obtain all required permits (PTW, hot work, confined space as applicable).
5. Brief all involved personnel on this SOP before starting.

### 5.2 Main Procedure

1. Verify all LOTO devices removed. Confirm no maintenance work in progress on this equipment.
2. Check all fluid levels: oil, coolant, and product supply as applicable.
3. Ensure all guards and safety interlocks are fitted and functional - test before starting.
4. Confirm utility services available: compressed air 6-7 bar, steam 5.5-7 bar, chilled water 2°C +/- 1°C.
5. Navigate to the equipment tag on SCADA. Acknowledge start permissives.
6. Start the equipment using the approved sequence. Observe initial parameter readings for 5 minutes.
7. Verify all parameters (temperature, pressure, flow, current) are within normal range (see equipment manual).
8. Record startup time, initial parameter readings, and operator name in the shift log.