

FreshFlow Beverages Pvt. Ltd.

FreshFlow Bottling Plant - Pune Production Facility
FSSAI: 10012022000345 | ISO 22000:2018 / ISO 14001:2015

STANDARD OPERATING PROCEDURE

Startup Procedure for Quality Line 99

Department: Quality

Document Number: SOP-099
Revision: Rev 2.3
Classification: CONFIDENTIAL - INTERNAL USE ONLY
Prepared by: Engineering / QA Department
Approved by: Plant Manager

Document Control Information

Parameter	Value
SOP Number	SOP-099
Title	Startup Procedure for Quality Line 99
Department	Quality
Plant	FreshFlow Bottling Plant - Pune Production Facility
Prepared By	Employee 4
Reviewed By	Rajesh Kulkarni
Approved By	Rajesh Kulkarni - Plant Manager
Issue Date	2021-06-02
Next Review Date	2027-12-28
Revision	Rev 2.1

1. Purpose

Ensure finished product, process parameters, and plant operations comply with FreshFlow quality specifications, HACCP plan, and regulatory requirements.

2. Scope

Quality Control team, Shift Supervisors, and Department Operators.

3. Prerequisites and Requirements

3.1 Training Requirements

- QC analyst training
- HACCP awareness training (ISO 22000)

3.2 Tools and Materials Required

- Calibrated instruments as listed in the plant calibration schedule.
- Appropriate PPE as specified in Section 4.
- Completed permit-to-work (if required for maintenance activities).
- Access to relevant equipment manual and P&ID drawings.
- CMMS access to create and close work orders.

4. Health, Safety and Environmental Requirements

! WARNING

This SOP must not be carried out without appropriate PPE and, where required, a valid Permit to Work (SOP-SAF-006). If in doubt about safety, STOP and consult the Safety Officer (EMP009 / EMP017).

4.1 Identified Hazards

- Laboratory chemicals - acids, alkalis, solvents
- Microbiological samples - BSL-1 biological hazard precautions

4.2 Emergency Response

In case of any emergency during this procedure: Press the nearest Emergency Stop, alert personnel in the vicinity, call the Safety Officer and Shift Supervisor. Refer to the Emergency Response Plan (SOP-SAF-004) and site evacuation procedure.

5. Detailed Procedure

5.1 Pre-Task Verification

1. Confirm the relevant equipment is available and no conflicting activities are planned.
2. Check shift handover log for any outstanding issues with this equipment.
3. Verify all required materials, tools, and chemicals are available and correctly labelled.
4. Obtain all required permits (PTW, hot work, confined space as applicable).
5. Brief all involved personnel on this SOP before starting.

5.2 Main Procedure

1. Verify all LOTO devices removed. Confirm no maintenance work in progress on this equipment.
2. Check all fluid levels: oil, coolant, and product supply as applicable.
3. Ensure all guards and safety interlocks are fitted and functional - test before starting.
4. Confirm utility services available: compressed air 6-7 bar, steam 5.5-7 bar, chilled water 2°C +/- 1°C.
5. Navigate to the equipment tag on SCADA. Acknowledge start permissives.
6. Start the equipment using the approved sequence. Observe initial parameter readings for 5 minutes.
7. Verify all parameters (temperature, pressure, flow, current) are within normal range (see equipment manual).
8. Record startup time, initial parameter readings, and operator name in the shift log.

6. Quality and Verification Checks

Verification Check	When	Responsible	Record
All product contact surfaces visually clean	Before production	Operator	Shift Log
CIP conductivity ≤ 20 uS/cm	After each CIP	Operator	CIP Record
CIP pH 6.5-7.5	After each CIP	Operator	CIP Record
Microbiological swab <10 CFU/cm ²	After each CIP	QC Lab	Micro Report
Key process parameters in normal range	At startup	Operator	SCADA Historian
First-off product sample - Brix, pH, CO ₂	After startup	QC Analyst	QC Lab Report

7. Non-Conformance and Escalation

If any check fails or if the procedure cannot be completed as written: STOP the task. Do not force equipment to operate outside specification. Escalate to the Shift Supervisor (Suresh Patil / Ravi Deshpande). Raise a Non-Conformance Report (NCR) in the CMMS system. QC Manager (Anita Desai) must be notified for any product safety impact.

8. Records and Documentation

Record Type	Frequency	Responsible	Storage Location
Shift Log - Quality	After each shift	Shift Supervisor	Shift Log Book / SCADA
CMMS Work Order	For every maintenance task	Technician	FreshFlow CMMS
CIP Record (FFB-QA-CIP-001)	After every CIP cycle	Operator	QA Filing System
Instrument Calibration Log	After calibration	QC/Maintenance	Calibration Database

A. Supplementary Notes

This SOP should be read in conjunction with the relevant equipment manual and the FreshFlow Beverages Good Manufacturing Practice (GMP) guidelines. Any suggested improvements to this SOP should be submitted to the Engineering Department using the Document Change Request (DCR) form FFB-ENG-DCR-001. This SOP is reviewed annually or whenever a significant process change occurs.

Related SOPs: SOP-SAF-002 (LOTO), SOP-GEN-010 (GMP), SOP-QA-005 (HACCP), SOP-GEN-001 (Shift Handover), SOP-GEN-006 (Plant Startup). For questions on this procedure, contact the Engineering or QA Department.